

# EPSON

EPSON - MUSTEPATRUUNATÄYTÖT	TYYPPI	NRO	VÄRI	SIVUJA	TÄYTTÖ
STYLUS PHOTO 790 /870 /875DC /890 /895 /915 /1270 /1290	T007401	T007	MUSTA	540	12,00
STYLUS PHOTO 790 / 870 / 875DC / 890 / 895 / 915	T008401	T008	5-VÄRI	220	18,00
STYLUS PHOTO 1270 / 1290	T009401	T009	5-VÄRI	330	16,00
STYLUS COLOR 480 / 580 / C20 / C40	T013401	T013	MUSTA	270	10,00
STYLUS COLOR 480 / 580 / C20 / C40	T014401	T014	3-VÄRI	150	16,00
STYLUS PHOTO 2000P	T015401	T015	MUSTA	350	12,00
STYLUS PHOTO 2000P	T016401	T016	5-VÄRI	250	20,00
STYLUS COLOR 680 / 685	T017401	T017	MUSTA	600	12,00
STYLUS COLOR 680 / 685	T018401	T018	3-VÄRI	300	18,00
STYLUS COLOR 880	T019401	T019	MUSTA	900	16,00
STYLUS COLOR 880	T020401	T020	3-VÄRI	300	16,00
STYLUS PHOTO 810 / 830 / 925 / 935	T026401	T026	MUSTA	540	12,00
STYLUS PHOTO 810 / 830 / 925 / 935	T027401	T027	5-VÄRI	220	20,00
STYLUS C60	T028401	T028	MUSTA	540	12,00
STYLUS C60	T029401	T029	3-VÄRI	300	18,00
STYLUS C42 PLUS / C42S / C42SX / C42UX / C44UX / C46	T036140	T036	MUSTA	300	10,00
STYLUS C42 PLUS / C42S / C42SX / C42UX / C44UX / C46	T037040	T037	3-VÄRI	180	16,00
STYLUS C62 / CX3200	T040140	T040	MUSTA	600	12,00
STYLUS C62 / CX3200	T041040	T041	3-VÄRI	300	18,00
STYLUS 400 / 440 / 460 / 500 / 600 / 640 / 660 / 670 / 700 / 750 /1200	T050140	T050	MUSTA		12,00
STYLUS 400 / 440 / 460 / 500 / 600 / 640 / 660 / 670 / 700 / 750 /1200	T051140	T051	3-VÄRI		16,00
STYLUS D78 / DX4000-DX8450 / S20-S21 / SX100-SX515 / BX300-BX600	T071140	T0711	BK	250	6,00
STYLUS D78 / DX4000-DX8450 / S20-S21 / SX100-SX515 / BX300-BX601	T071240	T0712	C	250	6,00
STYLUS D78 / DX4000-DX8450 / S20-S21 / SX100-SX515 / BX300-BX602	T071340	T0713	M	250	6,00
STYLUS D78 / DX4000-DX8450 / S20-S21 / SX100-SX515 / BX300-BX603	T071440	T0714	Y	250	6,00
Stylus Photo R265 / R285 / R360 / RX560 / RX585 / RX685	T080140	T0801	BK	250	6,00
Stylus Photo R265 / R285 / R360 / RX560 / RX585 / RX686	T080240	T0802	C	250	6,00
Stylus Photo R265 / R285 / R360 / RX560 / RX585 / RX687	T080340	T0803	M	250	6,00
Stylus Photo R265 / R285 / R360 / RX560 / RX585 / RX688	T080440	T0804	Y	250	6,00
STYLUS D68/D88/DX3800/DX3850/DX4200/DX4250/DX4800/DX4850	T061140	T0611	BK	250	6,00
STYLUS D68/D88/DX3800/DX3850/DX4200/DX4250/DX4800/DX4850	T061240	T0612	C	250	6,00
STYLUS D68/D88/DX3800/DX3850/DX4200/DX4250/DX4800/DX4850	T061340	T0613	M	250	6,00
STYLUS D68/D88/DX3800/DX3850/DX4200/DX4250/DX4800/DX4850	T061440	T0614	Y	250	6,00
STYLUS C84 / C86 / CX6400 / CX6600	T043140	T0431	BK HC	900	8,00
STYLUS C64 / C66 / C84 / C86 / CX3650 / CX6400 / CX6600	T044x40	T044x	BK/C/M/Y	420	6,00
STYLUS C64 / C66 / C84 / C86 / CX3650 / CX6400 / CX6600	T045x40	T045x	C/M/Y	420	6,00
STYLUS PHOTO R200/R220/R300/RX500/RX600/RX620	T048140	T048x	6 väriä	450	6,00
STYLUS PHOTO R800 / R1800	T054x40	T054x	BK/C/M/Y	550	6,00
STYLUS PHOTO RX420 / RX425 / RX520 / R240 / R245	T055x40	T055x	BK/C/M/Y	420	6,00
STYLUS C70 / C80 / C82 / CX5200 / CX5400	T032140	T0321	BK HC	1240	8,00
STYLUS C70 / C80	T032x40	T032x	C/M/Y	420	6,00
STYLUS C82 / CX5200 / CX5400	T042x40	T042x	C/M/Y	420	6,00